


## Product Structure



### ① Charging Contacts

### ② Power Indicator

Status	Indicator
Power ON	Static Blue
Low Battery	Static Red
Ultra-low Battery Warning	Blinking Red for 10 Seconds
Power OFF	Light Off

### ③ Power Button

Press and hold for 2 seconds to power ON or OFF.

### ④ Handheld Holder

### ⑤ USB-C Charging Port


For charging the Blink900 HM using the included USB-C charging cable.

### ⑥ Charging Indicator

Status	Indicator
Charging Blink900 HM	Static Red
Full Charged	Light Off

### ⑦ Belt-clip Slot

## Quick Setup Guide



1

Hold open the belt clip of the transmitter and slide it onto the belt clip slot of the handheld stand.

2

With the Hall function, the handheld stand will automatically turn on to charge the transmitter after it is attached in place.

3

When the transmitter is fully charged, press and hold the power button for 2 seconds to turn off the handheld stand.

#### Note:

1. This handheld stand can work with Blink900 TX, Blink900 TX-TG or Blink900 TXR (sold separately).
2. If no transmitter is attached to the stand within 30 seconds of power ON, the Blink900 HM handheld stand will automatically power OFF.



## Specifications

Power Capacity	Built-in Li-ion Battery 3.7V/1100mAh
Charging Port	USB-C
Charging Time	Approx. 2 hours
Charging Times for TX	Approx. 2 times
Dimensions	7.7x1.71x0.87" (195.5x43.5x22mm)
Weight	Approx. 2.33oz (66g)
Operating Temperature	0°C to 50°C
Storage Temperature	-20°C to +55°C

## Packing Lists



Handheld Microphone Holder x1



Foam Windscreen x1




USB-C Charging Cable x1



Scan the QR code and follow us  
扫描微信关注枫笛公众号

## 产品结构



- ① 充电触点  
② 电源指示灯


状态	指示灯
开机	蓝灯常亮
低电状态	红灯常亮
超低电警告	红灯闪烁10秒
关机	指示灯熄灭

- ③ 电源键  
长按电源键2秒开/关机。
- ④ 手柄  
使用随附的Type-C充电线给支架充电。
- ⑤ Type-C充电口
- ⑥ 充电指示灯

状态	指示灯
支架充电中	红灯常亮
支架充满电	红灯熄灭

- ⑦ 背夹凹槽

## 安装步骤




- ① 按压发射器背部的背夹，将发射器固定在手持支架上；

- ② 发射机安装到位后，支架因霍尔功能被激活将自动开机给发射器充电；

- ③ 充电完毕后，长按支架电源键2秒关机即可。

## 注：

1. 该手持支架适配Blink900 TX、Blink900 TX-TG和Blink900 TXR无线发射器（另售）。
2. Blink900 HM手持支架在开机30秒内若无发射器安装，将自动关机。



## 参数

电池规格	内置锂电池 3.7V/1100mAh
充电接口	Type-C
充电时长	约2小时
可给TX循环充电次数	约2次
尺寸	195.5x43.5x22mm
重量	66g
工作温度	0°C 至 50°C
贮存温度	-20°C 至 +55°C

## 配件清单



Blink900  
HM手持支架  
x 1



防风海绵  
x 1



Type-C  
充电线  
x 1



For better recording experience, the application **SmartRecorder** is recommended.  
为获得更好的录制体验，推荐使用枫笛 Saramonic 自主研发应用软件 **SmartRecorder**。

Shenzhen Jiayz Photo Industrial, Ltd  
深圳市长丰影像器材有限公司

A16 Building, Intelligent Terminal Industrial Park of Silicon Valley  
Power, Guanlan, Longhua District, Shenzhen, China  
深圳市龙华区观澜街道大富工业区硅谷动力智能终端产业园A16栋